

C-601

6 Channels Dimming Console


【USER MANUAL】

GENERAL FUNCTION (FRONT)

6 CH. OUTPUT
INDICATOR

6 CH. DIMMING
CONTROL SWITCHES





6 CH. FLASH CONTROL
SWITCHES



MASTER LED
INDICATOR

MASTER DIMMING
CONTROL

DIMENSION & CONNECTION



Lite-Puter Enterprise.Co. Ltd.

P.O. BOX 1-33 Hsi -Chih, Taipei, Taiwan

TEL 886-2-648-6545

FAX 886-2-648-6546

<http://www.liteputer.com>

E-Mail: litecom@ms2.hinet.net