

## EL-ML414-ML USER MANUAL



Before connecting, check if mains has an earth connection suitable to the characteristics of the lamp. The lamp should be connected to 220/240V and 50/60mHz, with an amperage of at least 6 Amps. Before using the spot, always disconnect the lamp from mains and check that there is no tension.

**ATTENTION** the machine has very hot parts inside; please wait until the machine has cooled down before opening.

Instructions for the Trilly Melody to operate properly:

- Follow the instructions printed on the machine
- Room temperature should not exceed 30°C, outside temperature maximum 120°
- Keep lamp 8 feet (2.5m) from flammable surfaces.
- Use proper lamps such as OSRAM HLX 64640 24V 150W, PHILLIPS 7158 24V 150W or other similar lamps.

Any repairs should be done by a qualified and authorized personnel to avoid warranty cancellation. Every test is certified by Alcatel test # REL.-QUAL.96/055 dated 05/25/96.

Please follow the instructions above and what is printed on the machine. The projector was not designed for continuous operation. The projector operates with temporary pauses.

### Technical Description

ELC 250w 24v lamp  
Sound Activation or DMX512  
Input via 3-Pin XLR  
Power 120v-50/60Hz  
Current draw: 7 Amps  
Size: 18.7"x8.7"x6.29"  
Weight: 7.7Kgs/ 16.9Lbs

### Spare Parts

Metal Body • Aluminum sides • Lens diameter 100 • Lens stop • Lamp socket GX 6.35 • Parable Colored Mirrors • Engine c/c 12/36 • Head piece with screws • Transformer 220/24 160W • Electronic card • Container with filter • Feeding cable 1.5mt • Microphone Rubber • Complete Screw • Ceramic connector • Bracket • Leaflet • Condenser



For more Information:  
Tel: (407) 857-8770  
Fax: (407) 857-8771  
[www.techni-lux.com](http://www.techni-lux.com)

M&L S.R.L. - Via del Lavoro, 35  
20040 BELLUSCO - (MI)  
Tel: 39 (039) 602 1469  
Fax: (039) 602 1944