

FM-GT1250

Gusto 1250 Fog Machine 1200w with TC-3 Remote, DMX 3 pin -120vAC

The advanced Gusto fog machine range features the latest in fog atmosphere producing technologies available today. All machines are thermally controlled to produce a safe, dry and consistent fog effect. To help prevent pump burnout, all Gusto units are fitted with a unique empty fluid tank sensor to prevent the dry running of pumps. However, the fluid containers are still removable for filling and cleaning purposes. The innovative and stylish shell design make maintenance most convenient and simple. This modular design allows quick access to the heater core, electronic circuit or pump easily when necessary. Standard with each machine is a remote and built-in DMX control. Gusto fog machines operate on professional water based fogging fluids.

■ Variable fog output ■ Truss mountable with yoke ■ Empty tank sensor ■ On-board DMX ■ Reduced nozzle blockage by using single piece diecast aluminum heater core

Specifications: Fog output: 20,000 cu/ft per minute ■ Tank capacity: 2 liters ■ Heater wattage: 1200 watts ■ Initial warm-up time: 7 minutes ■ Mounting yoke included ■ Carrying handle ■ Remote: TC-3 Timer interval, duration & variable volume output remote with 26' cable ■ DMX Channels: 1 or 3 ■ DMX In/Out: 3 Pin XLR ■ DMX start address using dip switch ■ Power: 120vAC 50/60hz ■ Fused: 13A ■ Size: 16.2" x 9.06" x 7.95" ■ Weight: 7.5Kgs/16.5Lbs ■ Color: Black & Silver ■ **Warranty:** 90 Days Limited

Fogger LED Indicator (Located behind and illuminates Fluid Tank)

RED Fogger is heating.
BLUE Heating element is off, fogger at full temperature and ready for maximum output.
<BLINKING> Fluid tank is empty (either RED or BLUE).

DMX Operation (Green LED near XLRs indicates presence of DMX signal)

DIP Switches 1-9 Set DMX Start Address
FDS1 Switch Set to "ON"
FDS2 Switch OFF: 1 channel control: 1) Volume 0-255 (0% to Full)
ON : 3 channel control: 1) Volume 2) Interval 3) Duration

TC-3 Remote Operation (Supplied with Fogger)

DIP Switches 1-9 Set all to "OFF"
FDS1 Switch Set to "ON"
FDS2 Switch Set to "OFF"

DMX Addressing

Switch	Value
1	1
2	2
3	4
4	8
5	16
6	32
7	64
8	128
9	256

TC-3 Remote

Duration Knob	Fogger Output Time (~0.5 to ~10 Seconds)
Interval Knob	Delay Time between Fogger Output (~9 to ~280 Seconds)
Volume Knob	Fogger Output Level (for Timer and Continuous Modes)
Timer Switch & Red LED	Enable/Disable Timer Function (Duration / Interval / Volume)
Continuous Switch & Red LED	Enable/Disable Continuous Function (Volume)
Manual Button	Momentary Full Output
Green LED	When lit, Fogger at full temperature and ready for maximum output

DC-3s LCD Display Remote Operation (Optional Remote)

DIP Switches 1-9 Set all to "OFF"
FDS1 Switch Set to "OFF"
FDS2 Switch *Not used, can be "OFF" or "ON"*